

## FAQ:

### 1. What headphone models and mobile systems does the app support?

1.1 Currently, it only supports CT3/CT3 pro headphones and is compatible with Android 9 and above/iOS 11 and above.

### 2. What if the sound quality is poor after restoring factory settings?

2.1 Try killing the blitzrock app process and reconnecting it.

### 3. EQ function/settings are unresponsive?

3.1 First, ensure both earbuds are out of the charging case and have power.

3.2 Are both earbuds connected to the system's Bluetooth (ensure both earbuds have audio output during playback)?

3.3 If both are out of the case, try restarting the system's Bluetooth or reconnecting them in the case.

### 4. Cannot connect the blitzrock app to the headphones or cannot find them?

4.1 Ensure other phone connections are disconnected.


4.2 Try restarting the system's Bluetooth. Try placing the headphones back in the charging case, closing the lid, and restarting the case.

4.3 Try restarting the app to reconnect.

### 5. Cannot control volume up/down with the headphone?

5.1 Please ensure the "Bluetooth device volume sync with phone" button is enabled in the system Bluetooth settings.

## Application



Google Play and the Google Play logo are trademarks of Google Inc.





Apple and the Apple logo are trademarks of Apple Inc.



Download the Blitzrock app to adjust EQ settings, update firmware, and explore more amazing features.

If your headphones are not connecting to the Blitzrock app, please reinstall the app or update it to the latest version in your mobile app store.

## PRODUCT INTERODUCTION






Charging Contacts



Charging Interface




 Please use the provided Type-C Charging Cable to charge.

## Wearing Instructions







1. Remove the earphones from the charging case.
2. Hang the earphones along the upper edge of your ear.
3. Slowly rotate the ear hook.
4. Adjust to the most comfortable and snug fit.

## CHARGING



## PAIRING




FUNCTION

		🎵	📶
	(1x) L/R	▶/⏸	🔄
	(2x) R	⏭	🔄 / 📶
	(2x) L	⏮	🔄 / 📶
	(3x) L/R	🗣️ Voice Assistant	/
	(4x) L/R	🎮 Toggle Game Mode	/
	(HOLD L)	🔊-	🔊-
	(HOLD R)	🔊+	🔊+

\*Please turn on game mode when you notice that the sound is lagged behind the video

\*Game mode is switched off by default.




Touch area

POWER ON/OFF


	With Headphone Case	Without Headphone Case
Power On	 Open the charging case	 Tap and hold for 3 seconds to power on a headphone individually.
Power Off	 Close the charging case	 Tap and hold for 5 seconds to power off a headphone individually

## Restore Factory Settings




When the headset is turned on, touch the left and right earphone touch positions 6 times at the same time. The earphone indicator light flashes white 3 times, and the headset is restored to factory settings.

## Firmware Update (OTA)



When you connect your headphones to the app, once a new firmware version is detected, please update the firmware version of your headphones for a better experience with the updated service.

SPECIFICATIONS



Brand	Blitzrock
Model	CT3
BT Version	BT5.4
BT Protocol	A2DP, HFP, HSP, AVRCP, SBC, AAC
Driver Unit Size	17*12mm
Charging Input	USB-C 5V = 0.5A
Battery Capacity(Earphones)	60mAh*2
Battery Capacity(Charging Case)	400mAh
Warranty	12 Months

Email: [service@blitzrockofficial.com](mailto:service@blitzrockofficial.com)